


SV15, SV15-2


> > SV15 > Vehicle > Fig. (38) SWING CYLINDER



Pos.	L.	Parts Number	~ ~>	-> ~	Description	I.	Q.	R.
1	1	172A5972600			CYLINDER ASSY,SWING	1		version TLM & CH
2	2	172A5972610			ROD (TLM)	1		
2	2	172A6072710			ROD (CHAPEL)	1		
4	3	172A5972630			SEAL (TLM)	4		
4	3	172A6072630			SEAL (CHAPEL)	4		
5	3	172A5972640			BUSH (TLM)	2		
5	3	172A6072640			BUSH (CHAPEL)	2		
6	2	172A5972650			HEAD (TLM)	1		
6	2	172A6072650			HEAD (CHAPEL)	1		
7	2	172A5972660			RING (TLM)	1		
7	2	172A6072660			RING (CHAPEL)	1		
8	2	172A5972670			NUT (TLM)	1		
8	2	172A6072670			NUT (CHAPEL)	1		
9	2	172A5972680			JEU DE JOINTS,SWING(TLM)	1		
9	2	172A6072680			JEU DE JOINTS,SWING(CHAPEL)	1		
10	2	172A5972740			TUBE ASSY, SWING (TLM)	1		
10	2	172A5972750			TUBE ASSY, SWING (CHAPEL)	1		
11	2	172A5972710			PISTON(TLM)	1		
11	2	172A6072930			PISTON(CHAPEL)	1		

SV17, SV17-2, SV17E, SV17-EX2

> > SV17 > Vehicle > Fig. (40) SWING CYLINDER



Pos.	L.	Parts Number	~ ->	-> ~	Description	I.	Q.	R.
1	1	172A5972600			CYLINDER ASSY,SWING (TLM)		1	
1	1	172A5972600			CYLINDER ASSY,SWING (CHAPEL)		1	
2	2	172A5972610			ROD (TLM)		1	
2	2	172A6072710			ROD (CHAPEL)		1	
4	3	172A5972630			SEAL (TLM)		4	
4	3	172A6072630			SEAL (CHAPEL)		4	
5	3	172A5972640			BUSH (TLM)		2	
5	3	172A6072640			BUSH (CHAPEL)		2	
6	2	172A5972650			HEAD (TLM)		1	
6	2	172A6072650			HEAD (CHAPEL)		1	
7	2	172A5972660			RING (TLM)		1	
7	2	172A6072660			RING (CHAPEL)		1	
8	2	172A5972670			NUT (TLM)		1	
8	2	172A6072670			NUT (CHAPEL)		1	
9	2	172A5972680			JEU DE JOINTS,SWING(TLM)		1	
9	2	172A6072680			JEU DE JOINTS,SWING(CHAPEL)		1	
10	2	172A5972740			TUBE ASSY, SWING (TLM)		1	
10	2	172A5972750			TUBE ASSY, SWING (CHAPEL)		1	
11	2	172A5972710			PISTON(TLM)		1	
11	2	172A6072930			PISTON(CHAPEL)		1	